



Swellendam FASX

Joining info

Rev. 2018/01-1

34°03'00' S
20°29'00' E

ELEV – 407 FT AMSL

FREQ – 124.8 MHz

Location:

FASX is 5nm South-East of the town of Swellendam.

Radio call:

Alert FASX and other aircraft on 124.8 MHz – Normally there is no ATC on duty.
For Fly-In and Aerobatic Regionals from 3-4 Mar 2018 – ATC on 124.8 MHz.

Standard joining procedures apply:

Join over-head at 2000' AGL (2500' AMSL) on last known QNH.

Visibility:

Switch on all lights to attract attention and look out for other traffic.

Circuit and parking:

A left hand circuit is in use for all runways. Parking is North of the hangars.
Secondary runway at 06 and 24, 600m grass with no lights.

Lights on runway 15 and 33:

Runways light are controlled by an automatic day-night switch.

Low flying:

FASX is situated next the Bontebok National Park. Please avoid unnecessary low flying on the park-side of the airfield as far as possible, as a courtesy to the park, its visitors and animals.

Contact Details:

Chairperson:	Pieter Venter	083 250 9504
Fuel:	Person on duty	076 767 3907
CFI:	Donald Buxton	082 552 4126

Emergency Numbers:

Ambulance:	Regional	10177
Hospital:	Swellendam	028 514 1140
Fire:	Regional	10177
Police:	Swellendam	028 514 8102

PARK-SIDE

MOUNTAIN-SIDE

